


Цанги ER

Подпружиненные цанги ER DIN 6499 (Повышенной точности)



ER11, 16, 20-SPR-AA

Кат. №	Диапазон (mm)
ER11SPR0.5-1AA	0.5 - 1
ER11SPR1-2AA	1 - 2
ER11SPR2-3AA	2 - 3
ER11SPR3-4AA	3 - 4
ER11SPR4-5AA	4 - 5
ER11SPR5-6AA	5 - 6
ER11SPR6-7AA	6 - 7
ER16SPR0.5-1AA	0.5 - 1
ER16SPR1-2AA	1 - 2
ER16SPR2-3AA	2 - 3
ER16SPR3-4AA	3 - 4
ER16SPR4-5AA	4 - 5
ER16SPR5-6AA	5 - 6
ER16SPR6-7AA	6 - 7
ER16SPR7-8AA	7 - 8
ER16SPR8-9AA	8 - 9
ER16SPR9-10AA	9 - 10
ER20SPR1-2AA	1 - 2
ER20SPR2-3AA	2 - 3
ER20SPR3-4AA	3 - 4
ER20SPR4-5AA	4 - 5
ER20SPR5-6AA	5 - 6
ER20SPR6-7AA	6 - 7
ER20SPR7-8AA	7 - 8
ER20SPR8-9AA	8 - 9
ER20SPR9-10AA	9 - 10
ER20SPR10-11AA	10 - 11
ER20SPR11-12AA	11 - 12
ER20SPR12-13AA	12 - 13

ER25, 32-SPR-AA

Кат. №	Диапазон (mm)
ER25SPR1-2AA	1 - 2
ER25SPR2-3AA	2 - 3
ER25SPR3-4AA	3 - 4
ER25SPR4-5AA	4 - 5
ER25SPR5-6AA	5 - 6
ER25SPR6-7AA	6 - 7
ER25SPR7-8AA	7 - 8
ER25SPR8-9AA	8 - 9
ER25SPR9-10AA	9 - 10
ER25SPR10-11AA	10 - 11
ER25SPR11-12AA	11 - 12
ER25SPR12-13AA	12 - 13
ER25SPR13-14AA	13 - 14
ER25SPR14-15AA	14 - 15
ER25SPR15-16AA	15 - 16
ER32SPR2-3AA	2 - 3
ER32SPR3-4AA	3 - 4
ER32SPR4-5AA	4 - 5
ER32SPR5-6AA	5 - 6
ER32SPR6-7AA	6 - 7
ER32SPR7-8AA	7 - 8
ER32SPR8-9AA	8 - 9
ER32SPR9-10AA	9 - 10
ER32SPR10-11AA	10 - 11
ER32SPR11-12AA	11 - 12
ER32SPR12-13AA	12 - 13
ER32SPR13-14AA	13 - 14
ER32SPR14-15AA	14 - 15
ER32SPR15-16AA	15 - 16
ER32SPR16-17AA	16 - 17
ER32SPR17-18AA	17 - 18
ER32SPR18-19AA	18 - 19
ER32SPR19-20AA	19 - 20

ER40-SPR-AA

Кат. №	Диапазон (mm)
ER40SPR3-4AA	3 - 4
ER40SPR4-5AA	4 - 5
ER40SPR5-6AA	5 - 6
ER40SPR6-7AA	6 - 7
ER40SPR7-8AA	7 - 8
ER40SPR8-9AA	8 - 9
ER40SPR9-10AA	9 - 10
ER40SPR10-11AA	10 - 11
ER40SPR11-12AA	11 - 12
ER40SPR12-13AA	12 - 13
ER40SPR13-14AA	13 - 14
ER40SPR14-15AA	14 - 15
ER40SPR15-16AA	15 - 16
ER40SPR16-17AA	16 - 17
ER40SPR17-18AA	17 - 18
ER40SPR18-19AA	18 - 19
ER40SPR19-20AA	19 - 20
ER40SPR20-21AA	20 - 21
ER40SPR21-22AA	21 - 22
ER40SPR22-23AA	22 - 23
ER40SPR23-24AA	23 - 24
ER40SPR24-25AA	24 - 25
ER40SPR25-26AA	25 - 26

