

Цанги ER

Подпружиненные цанги ER DIN 6499



ER11, 16, 20-SPR

| Кат. № | Диапазон (mm) |
|--------------|---------------|
| ER11SPR0.5-1 | 0.5 - 1 |
| ER11SPR1-2 | 1 - 2 |
| ER11SPR2-3 | 2 - 3 |
| ER11SPR3-4 | 3 - 4 |
| ER11SPR4-5 | 4 - 5 |
| ER11SPR5-6 | 5 - 6 |
| ER11SPR6-7 | 6 - 7 |
| ER16SPR0.5-1 | 0.5 - 1 |
| ER16SPR1-2 | 1 - 2 |
| ER16SPR2-3 | 2 - 3 |
| ER16SPR3-4 | 3 - 4 |
| ER16SPR4-5 | 4 - 5 |
| ER16SPR5-6 | 5 - 6 |
| ER16SPR6-7 | 6 - 7 |
| ER16SPR7-8 | 7 - 8 |
| ER16SPR8-9 | 8 - 9 |
| ER16SPR9-10 | 9 - 10 |
| ER20SPR1-2 | 1 - 2 |
| ER20SPR2-3 | 2 - 3 |
| ER20SPR3-4 | 3 - 4 |
| ER20SPR4-5 | 4 - 5 |
| ER20SPR5-6 | 5 - 6 |
| ER20SPR6-7 | 6 - 7 |
| ER20SPR7-8 | 7 - 8 |
| ER20SPR8-9 | 8 - 9 |
| ER20SPR9-10 | 9 - 10 |
| ER20SPR10-11 | 10 - 11 |
| ER20SPR11-12 | 11 - 12 |
| ER20SPR12-13 | 12 - 13 |

ER25, 32-SPR

| Кат. № | Диапазон (mm) |
|--------------|---------------|
| ER25SPR1-2 | 1 - 2 |
| ER25SPR2-3 | 2 - 3 |
| ER25SPR3-4 | 3 - 4 |
| ER25SPR4-5 | 4 - 5 |
| ER25SPR5-6 | 5 - 6 |
| ER25SPR6-7 | 6 - 7 |
| ER25SPR7-8 | 7 - 8 |
| ER25SPR8-9 | 8 - 9 |
| ER25SPR9-10 | 9 - 10 |
| ER25SPR10-11 | 10 - 11 |
| ER25SPR11-12 | 11 - 12 |
| ER25SPR12-13 | 12 - 13 |
| ER25SPR13-14 | 13 - 14 |
| ER25SPR14-15 | 14 - 15 |
| ER25SPR15-16 | 15 - 16 |
| ER32SPR2-3 | 2 - 3 |
| ER32SPR3-4 | 3 - 4 |
| ER32SPR4-5 | 4 - 5 |
| ER32SPR5-6 | 5 - 6 |
| ER32SPR6-7 | 6 - 7 |
| ER32SPR7-8 | 7 - 8 |
| ER32SPR8-9 | 8 - 9 |
| ER32SPR9-10 | 9 - 10 |
| ER32SPR10-11 | 10 - 11 |
| ER32SPR11-12 | 11 - 12 |
| ER32SPR12-13 | 12 - 13 |
| ER32SPR13-14 | 13 - 14 |
| ER32SPR14-15 | 14 - 15 |
| ER32SPR15-16 | 15 - 16 |
| ER32SPR16-17 | 16 - 17 |
| ER32SPR17-18 | 17 - 18 |
| ER32SPR18-19 | 18 - 19 |
| ER32SPR19-20 | 19 - 20 |

ER40, 50-SPR

| Кат. № | Диапазон (mm) |
|--------------|---------------|
| ER40SPR3-4 | 3 - 4 |
| ER40SPR4-5 | 4 - 5 |
| ER40SPR5-6 | 5 - 6 |
| ER40SPR6-7 | 6 - 7 |
| ER40SPR7-8 | 7 - 8 |
| ER40SPR8-9 | 8 - 9 |
| ER40SPR9-10 | 9 - 10 |
| ER40SPR10-11 | 10 - 11 |
| ER40SPR11-12 | 11 - 12 |
| ER40SPR12-13 | 12 - 13 |
| ER40SPR13-14 | 13 - 14 |
| ER40SPR14-15 | 14 - 15 |
| ER40SPR15-16 | 15 - 16 |
| ER40SPR16-17 | 16 - 17 |
| ER40SPR17-18 | 17 - 18 |
| ER40SPR18-19 | 18 - 19 |
| ER40SPR19-20 | 19 - 20 |
| ER40SPR20-21 | 20 - 21 |
| ER40SPR21-22 | 21 - 22 |
| ER40SPR22-23 | 22 - 23 |
| ER40SPR23-24 | 23 - 24 |
| ER40SPR24-25 | 24 - 25 |
| ER40SPR25-26 | 25 - 26 |
| ER50SPR10-12 | 10 - 12 |
| ER50SPR12-14 | 12 - 14 |
| ER50SPR14-16 | 14 - 16 |
| ER50SPR16-18 | 16 - 18 |
| ER50SPR18-20 | 18 - 20 |
| ER50SPR20-22 | 20 - 22 |
| ER50SPR22-24 | 22 - 24 |
| ER50SPR24-26 | 24 - 26 |
| ER50SPR26-28 | 26 - 28 |
| ER50SPR28-30 | 28 - 30 |
| ER50SPR30-32 | 30 - 32 |
| ER50SPR32-34 | 32 - 34 |

